

Extendable hoisting beams

Extendable hoisting beams are designed for hoisting long loads of various types. The hooks on the jib swivel and are adjustable to obtain optimal load balance



	Capacity	Lenght	Adjustable	Weight
EVU05	5000-3000 kg	2400-3500 mm	2400-3500 mm	175 kg
EVU06	6000-2000 kg	2400-6000 mm	2400-6000 mm	175 kg
EVU08	8000-5000 kg	2400-3500 mm	2400-3500 mm	255 kg
EVU10	10000-4000 kg	2400-6000 mm	2400-6000 mm	535 kg
EVU12	12000-8000 kg	2400-3500 mm	2400-3500 mm	320 kg

Adjustable hoisting beams

This hoist is designed to lift a variety of long loads. The hooks on the jib swivel and are adjustable to obtain optimal load balance.



	Capacity	Length	Adjustable	Weight
EVE200	2000 kg	2000 mm	2000-720 mm	44 kg
EVE300	3000 kg	3000 mm	3000-1200 mm	85 kg
EVE400	4000 kg	4000 mm	4000-1900 mm	135 kg
EVE500	5000 kg	5000 mm	5000-2200 mm	200 kg

Accessories

EVE200V

Hoisting beam feet for EVE200

These feet can be used on an EVE200 type hoisting beam. This will allow the hoisting beam to stand upright when disconnected. It will prevent damage to the beam when laying it on the ground.

EVE300V

Hoisting beam feet for EVE300

These feet can be used on an EVE300 type hoisting beam. This will allow the hoisting beam to stand upright when disconnected. It will prevent damage to the beam when laying it on the ground.

EVE400V

Hoisting beam feet for EVE400

These feet can be used on an EVE400 type hoisting beam. This will allow the hoisting beam to stand upright when disconnected. It will prevent damage to the beam when laying it on the ground.

EVE500V

Hoisting beam feet for EVE500

These feet can be used on an EVE500 type hoisting beam. This will allow the hoisting beam to stand upright when disconnected. It will prevent damage to the beam when laying it on the ground.